

# SEAFLO<sup>®</sup>

## READ CAREFULLY BEFORE INSTALLATION AND USE

---

### **TO THE FITTER:**

Ensure all relevant personal read the points listed below and that a copy is passed on to the end-user.

### **TO THE USER:**

Read the points listed below before installation and use of equipment.

This bilge pump is designed to exhaust standing water. Output capacity depends on installation conditions and pumping rate.

Users should be aware that capacity may not be sufficient to cope with rapid influx of water.

If it is intended for use with any other liquid it is the user's responsibility to ensure that the materials are fully compatible with the liquids to be used and that a system of safe working practice is applied to installation, use and maintenance.

A planned maintenance schedule of regular inspection is recommended.

The manufacturer cannot be held responsible for claims arising from incorrect installation, unauthorized modification or misuse of the product.